



red holes (outer) are for wire ties blue/inner holes for clips use either but not both
Clip is digikey 283-2337-ND